## **Smart Device Communications**

@DEVCOM\_ACTIONS

Command used to communicate with a device supporting the AK protocol.

## **Keyword:**

@DEVCOM\_ACTIONS

**Usage:** 

## **Data Fields:**

start_code	code for when to send the command - options are AT_START or AFTER_STABILITY - default is AT_START
	code for what action to take when communication is complete - options are NONE, MODE_TERMINATE, RETURN, a mode number, or a procedure file pathname - default is NONE
fail_path	code for what action to take if communication fails - options are NONE, MODE_TERMINATE, RETURN, a mode number, or a procedure file pathname - default is NONE

## **Example Specification:**

@DEVCOM\_ACTIONS #start\_code

#start\_code success\_path fail\_path
AT\_START MODE\_TERMINATE /specs/gp/quit